Product Manual | Manuel du Produit | Manual del Producto



FB2400

Introduction

Thank you for purchasing the Atlantic FB2400 Fountain Basin.

Installation

Begin by excavating a hole at least 4 inches larger than the basin and $9\frac{1}{2}$ " deep. This depth will leave the Fountain Basin slightly higher than the ground around it, keeping soil, mulch or gravel from washing in. Angling the sides of the hole outward slightly will aid in the backfill process. Set the Fountain Basin on level, undisturbed soil.

Important! Do not dig too deep.

The Fountain Basin should be set on undisturbed earth if possible. In case you do over-dig, be sure to compact the soil thoroughly to prevent settling. The bottom of the hole must also be level side-to-side and front-to-back (Figure 1).

Add enough water to the Fountain Basin to keep it from shifting during the backfill process. Use loose soil from the excavation to fill the void around the perimeter of the basin. Carefully compact the soil around the basin as you backfill.

Over-compacting can distort and/or damage the Fountain Basin (Figure 2).

Atlantic Oasis Fountain Basins are designed to work with Atlantic Fountain Pumps, featuring built-in flow control for fast, easy flow adjustment. Attach one end of the hose provided to the barbed outlet at the top of the Fountain Pump and secure with a hose clamp (Figure 3).

Figure 1



Figure 2



Figure 3



Pull the other end of the hose out through the predrilled hole onto the surface of the Fountain Basin. Choose one of the channels, then run the tubing to the center of the Basin and attach the appropriate fitting, which will depend on the decorative fountain piece (Figure 4).

Set the decorative piece over the fitting, then attach the ½" standpipe to the fitting. Cut the standpipe to just below the water surface to create a bubbling effect. Seal any gaps between the standpipe and the base of the pot with Atlantic SPSEAL. To center and stabilize the standpipe, place a few rocks around it inside the decorative piece to support it. Figure 5 shows the fountain ready for water. Fill the Basin with water, connect the pump to a GFI-protected outlet and adjust flow as necessary (Figure 5).

To complete installation, cover the Fountain Basin with gravel, polished stones, glass beads or other decorative material. To disguise the square outline of the Basin further, extend the material past the edge of the Basin. To enhance nighttime enjoyment of the fountain, complement your Fountain Basin with Atlantic's LED lighting (Figure 6).

Warranty

This product carries a lifetime warranty. This warranty is extended solely to the original purchaser commencing from the date of original purchase receipt. A misused or abused product voids this warranty.

Warranty Claims

In case of warranty claims, the complete lonizer should be returned to the place of purchase accompanied by original receipt.

Figure 4



Figure 5



Figure 6



