



In a level intake installation, the At-Rest water level in the water feature will be at the bottom of the overflow port.



The At-Rest water level in the pond is determined by the overflow level inside the Filter Tank. The highest overflow level is 2.50" down from the top of Filter Tank.



The Filter Tank Rim is placed level with the rim of the water feature.

